seethelight

Internet User Guide

For use with the Zyxel NBG4604 Routers

Internet User Guide

1. Your fibre equipment	3
2. Setting up your internet connection	7
2.1 Before you begin	8
2.2 A 'wired' connection	9
2.3 A 'wireless' connection	10
2.4 A 'wired' connection using the patch panel	11
3. Configuring your router	15
3.1 Changing the admin password	15
4. About your router	16
5. Router Reset Procedure	17
6. Connecting to wireless networks	18
6.1 Windows Vista	19
6.2 Windows XP	21
6.3 MAC OS X - version 10.4	24
6.4 Windows 7	26
6.5 Windows 8	28
6.6 OSX Lion/Mountain Lion	28
7. Internet troubleshooting	29

Please note: This guide is for Zyxel NBG4604 routers only.

This is fibre: this is the future

Welcome to the next-generation of communications: future-proof, cutting-edge technology that allows for more entertainment, a richer experience and super-fast downloads. Seethelight deliver high-speed internet via fibre optics that makes hi-tech applications, home working and video conferencing a reality.

Brace yourself – the broadband you've used in the past doesn't compare to fibre's stunning connectivity. It's worth looking out for the little differences from traditional data services – but don't worry, we'll be covering them in the next few pages.

Please ensure that you read this guide carefully to help you get the best out of your seethelight services.

1. Your fibre equipment

Because seethelight use fibre to bring you high-speed internet, we use some equipment that you may not be familiar with.
This next section will give you a quick overview of this equipment.

Your home will have **either** of these two set-ups:

Configuration A:

Patch panel linked to internal wiring to enable internet service in multiple rooms.*



*Exact layout of equipment may vary. Your internal wiring is the responsibility of the house owner/landlord. To resolve an internal wiring problem please contact a qualified electrician. If a seethelight technician visits your premises and the issue is caused by an internal wiring fault, you may be charged a call out fee.

Geek Speak:

Fibre is short for 'fibre optics'. Fibre optics are small glass threads through which light is passed. Internet and voice data is converted from electrical impulses into light, passed down the fibre as light, then converted back into electrical impulses. This allows data to flow up and down the fibre.

Configuration B:
The same as 'A' but with no patch panel.*



*Exact layout of equipment may vary

ONT (Optical Network Terminal)

This is where the light that passes through the fibre optics on the seethelight network is converted into electrical signals for use by your telephone or computer. The ONT is typically located in an under stairs cupboard (though this may vary from house to house). It has two or four internet and two telephony ports situated on the underside.

Note: Make sure your ONT's power supply is plugged-in and switched on or you will not have a connection to the seethelight network for both telephony and internet.

The ONT has several lights located on it, which tell you its status. These lights can be useful to help you troubleshoot any problems with your connection. The table below describes the lights which may indicate a problem with your connection.

Please note, the lights may vary between different versions of the ONT.

Light name	Colour	Meaning
EQPT	Off	No power*
	Green	OK
MGMT	Off	No power*
	Green	OK
	Red, Amber or Flashing	No connection*
Power	Green	Power OK
	Off	No power*
PON	Green	Connection OK
	Red	No connection**
WAN	Green	Connection OK
	Red	No connection**
LOS	Red	No connection**

	Action
*	Check power and other cables are properly connected.
**	Check that there are no bends in the fibre connection.

Battery Back-Up

This useful piece of kit provides back-up battery power, so if the mains power fails, you will still be able to make telephone calls for up to eight hours. Please note that Internet services are not supported when your ONT is running on battery back-up power.

Patch Panel

This can be used to distribute data services throughout the home via internal cabling. Using the patch cables between the socket and the ONT, you can deliver services wherever they are needed in the home (for more on this see **2.4 A 'wired' connection using the patch panel**)

Telephony Master Socket and Telephone Adaptor

Applicable for voice services. Please see Telephone User Guide for more information.

2. Setting up your internet connection

Make sure you have the following:

Wireless Zyxel Router

Network Ethernet Cable (colour may vary)



Router Power Supply



And make sure you can locate your ONT (for more on this, see **1. Your Fibre Equipment**)



2.1 Before you begin

Your set-up options:

- A 'wired' connection from your Zyxel router to your PC/internet device (see page 9)
- A 'wireless' connection for your PC/internet device (see page 10)
- A 'wired' connection using your house's internal wiring (see page 11)

Think about...

- Whether you want to connect your computer using a 'wireless' or 'wired' connection
- If you want the best download and upload speeds available, then use a 'wired' connection to your router as internet speeds slow down over wireless connections

If you want to go 'wireless'...

- If you have a PC/laptop (made in the last six years), or Apple Mac then you will be ready to go, as it will be'wireless enabled' as standard.

If your computer isn't 'wireless enabled', you'll need the following equipment:

- For laptop: Wireless USB adaptor or wireless PCMCIA card
- For PC: Wireless USB adaptor or wireless network card

And finally...

- Follow these instructions closely
- Don't turn on your power supply until you're sure everything is connected correctly
- Don't attempt to disassemble any of your seethelight equipment

2.2 A 'wired' connection

This diagram shows a 'wired' connection from your router to your PC/internet device:



1. Insert ethernet cable into **internet port 1** of the ONT.

2. Take the other end of this cable and insert it into **blue WAN port** of your router. Take another ethernet cable and plug it into any of your router's remaining ports (labelled 1-4). You can then connect your PC/or other internet enabled device to the other end of this ethernet cable.

3. Connect to your PC/internet enabled device through its internet port.

2.3 A 'wireless' connection

This diagram shows a 'wireless' connection from your router to your PC/internet device:



1. Insert ethernet cable into **internet port 1** of the ONT.

2. Take the other end of this cable and insert it into **blue WAN port** of your router. For information on how to connect to wireless networks, see **6. Connecting to wireless networks**.

2.4 A 'wired' connection using the patch panel

This diagram shows a 'wired' connection using your house's internal wiring and patch panel (where fitted):



1. Insert ethernet cable into **internet port 1** of the ONT.

2. Take the other end of this cable and insert it into **blue WAN port** of your router. Take another ethernet cable and plug it into any of your router's remaining ports (labelled 1-4).

3. Take the other end of this second ethernet cable and plug it into the relevant socket on the patch panel associated with the room where you would like service provided. For example, if you wish to enable internet service to your study, connect the ethernet cable into the socket marked 'study' or the number corresponding to the room socket ID.

4. Using another ethernet cable, take one end and plug it into a wall socket in the relevant room that your internet service has been enabled to.

5. With the other end of this cable, connect to your PC/internet-enabled device through its internet port.

Note: You can enable your internet service to more rooms by adding additional ethernet cabled connections between your router and your patch panel as shown in the diagram below:



1. Take another ethernet cable and plug it into any of your router's remaining ports (labelled 1-4).

2. Then take the other end of this ethernet cable and plug it into the relevant socket on the patch panel associated with the room where you would like service provided.

3. Using another ethernet cable, take one end and plug it into a wall socket in the relevant room that your internet service has been enabled to.

4. With the other end of this cable, connect to your PC/internet-enabled device through its internet port.

3. Configuring your router

Note: If you plan to connect your computer via a wireless connection then please configure your computer as described in 6. Connecting to wireless networks and then continue with this section.

Your router is shipped pre-configured and is ready to be connected to the network. If you do need to login to your router, then enter http://192.168.1.254 into your web browser and when promoted, enter the username admin and the password quick.

3.1 Changing the admin password

Seethelight recommend that you change your router's default password (quick) to something else to help keep your computer safe online. Use the following procedure to change your password and ensure that you make a note of your new password.

Launch your web browser and type http://192.168.1.254 into your web browser's address bar, then press enter. Enter the username admin and the default password quick into the router's web page. Now click Advanced Setup and navigate to Maintenance then System.

4. About your router

On the top of your router, you will find a number of status LEDs that indicate the status of the device. These lights can be useful to help you troubleshoot any problems with your connection.

LED	COLOUR	STATUS	DESCRIPTION
POWER	Green	On	The NBG4604 is receiving power and functioning properly.
		Off	The NBG4604 is not receiving power.
WLAN	Green	On	The NBG4604 is ready, but is not sending/ receiving data through the wireless LAN.
		Blinking	The NBG4604 is sending/receiving data through the wireless LAN. The NBG4604 is negotiating a WPS connection with a wireless client.
		Off	The wireless LAN is not ready or has failed.
WPS	Green	On	The NBG4604 is ready, but is not sending/ receiving data through the WPS connection.
		Blinking	The NBG4604 is sending/receiving data through the WPS connection.
		Off	The WPS connection not ready or has failed.
WAN	Green	On	The NBG4604 has a successful 10/100/1000 MB WAN connection.
		Blinking	The NBG4604 is sending/receiving data through the WAN.
		Off	The WAN connection is not ready, or has failed.
LAN 1-4	Green	On	The NBG4604 has a successful 10/100/1000 MB Ethernet connection.
		Blinking	The NBG4604 is sending/receiving data through the LAN.
		Off	The LAN is not connected.
WPS Button	Press this button for 1 second to set up a wireless connection via WiFi Protected Setup with another WPS-enabled client. You must press the WPS button on the client side within 120 seconds for a successful connection.		

5. Router reset procedure

If you encounter problems, perform a hardware reset of your router back to factory defaults and then refer to section 3. Configuring your router.

To perform a hardware reset:

1. Make sure your router is turned on.

2. Use a pen or paperclip to push the recessed 'reset' button, push and hold until the power light turns red (approx. 7 seconds).

6. Connecting to wireless networks

You will find a sticker attached to the underside of your router. It will contain the following information:

- Your SSID: The name of your wireless network associated with your router
- WPA2 PSK: The password you will need to enter on your PC's wireless client to gain access to this network

You will find instructions on how to set up a wireless connection for the following operating systems:

- Windows Vista (see page 19)
- Windows XP (see page 21)
- MAC OSX - version 10.4 (see page 24)
- Windows 7 (see page 26)
- Windows 8 (see page 28)
- OSX Lion/Mountain Lion (see page 28)

IMPORTANT: If you don't have any of the above operating systems, or if you use a non-standard wireless client, then please consult the appropriate manufacturer manual.

Geek Speak:

SSID: Or Service Set Identifier, is used to identify wireless networks. By displaying a list of SSIDs in your range you can select one to connect to.

WPA2: Security protocols used to secure wireless computer networks.

6.1 Windows Vista

1. Click on the 'Start' button and then click 'Connect To'.



2. Now click on the network that you want to connect to (your SSID), then click 'Connect'





3. Now enter your network password (WPA2 PSK) then click 'Connect'.


Connect to a network
Type the network security key or passphrase for STL_Customer_50
The person who setup the network can give you the key or passphrase.
Security key or passphrase:
Display characters
If you have a USB flash drive with network settings for STL_Customer_50, insert it now.
Connect
Cancel

6.2 Windows XP

1. First, right-click the wireless network icon located in the lower right corner of your screen or go to 'Connect To' on the start menu.



2. Click 'View Available Wireless Networks'.



3. A window will appear displaying the wireless networks in your vicinity. Click on your network (your SSID) and then click 'Connect'.


Wireless Network Connection
Network Tasks
Refresh network list
Set up a wireless network for a home or small office
Related Tasks
Learn about wireless networking
Change the order of preferred networks
Change advanced settings
Choose a wireless network
Click an item in the list below to connect to a wireless network in range or to get more information.
seethelight
Security-enabled wireless network (WPA)
Connect

4. Now enter your network password (WPA2 PSK).


Wireless Network Connection
Network Tasks
Refresh network list
Set up a wireless network for a home or small office
Related Tasks
Learn about networking
Change the preferred ne
Change adv settings
Choose a wireless network
Click an item in the list below to connect to a wireless network in range or to get more information.
Wireless Network Connection
The network 'seethelight' requires a network key (also called a WEP key or WPA key). A network key helps prevent unknown intruders from connecting to this network.
Type the key, and then click Connect.
Network key:
Confirm network key:
Connect
Cancel
additional information.
Connect

5. When you have done this, click 'Connect'.


Wireless Network Connection
Network Tasks
Refresh network list
Set up a wireless network for a home or small office
Related Tasks
Learn about networking
Change the preferred ne
Change adv settings
Choose a wireless network
Click an item in the list below to connect to a wireless network in range or to get more information.
Wireless Network Connection
The network 'seethelight' requires a network key (also called a WEP key or WPA key). A network key helps prevent unknown intruders from connecting to this network.
Type the key, and then click Connect.
Network key:
Confirm network key:
Connect
Cancel
additional information.
Connect

6. You should now be connected to your wireless network.


Wireless Network Connection
Network Tasks
Refresh network list
Set up a wireless network for a home or small office
Related Tasks
Learn about wireless networking
Change the order of preferred networks
Change advanced settings
Choose a wireless network
Click an item in the list below to connect to a wireless network in range or to get more information.
seethelight
Connected
Security-enabled wireless network (WPA)
Connect

6.3 MAC OS X - version 10.4

1. Go to the 'System Preferences' icon on your dock, then click on 'Network' under the 'Internet & Network' heading.

2. Click on the 'Turn AirPort On' button.



3. Select the correct network (your SSID) from the 'Network Name' list.


Network
Show All
Location: Automatic
Bluetooth
Not Connected
AirPort
No IP Address
USB Ethernet
Not Connected
Status: On
Turn AirPort Off
AirPort does not have an IP address and cannot connect to the Internet.
Network Name: seethelight
Ask to join new networks
Known networks will be joined automatically. If no known networks are available, you will be asked before joining a new network.
Show AirPort status in menu bar
Advanced...

4. Now enter your network password (WPA2 PSK) then click 'OK' followed by 'Apply'.

6.4 Windows 7

1. Click the 'Start' button and right click on 'Computer' and 'Properties' and select 'Device Manager'.



2. Click the arrow next to 'Network Adaptors to see if there is a WiFi adaptor listed. If you don't have a wireless adaptor, you will have to buy one to plug into one of your computer's USB ports.



3. To connect to a wireless network, click the wifi icon. You should now see a list of available networks.

4. To connect to a network, just click on its name. If it's a secure network and it's the first time you've used it, you'll need a password. If it's your home network, your internet provider will have given you a password – sometimes it's printed on a sticker attached to the router.
If you'll be using the same connection regularly, you can tick the box to connect automatically.

5. The first time you connect to a network, you'll be asked to choose whether it's a home, work or public network.

6.5 Windows 8

1. Move the mouse cursor to the upper right corner of the screen until the charms bar appears. Select 'Settings' and then select 'WiFi'.

2. Select the wireless network you wish to connect to, and click on connect. You will be asked to enter your password.

6.6 OSX Lion/Mountain Lion

1. Click on the AirPort icon in your menu bar and you will be presented with a list of visible wireless networks. Select the correct Network you wish to join.



2. If the network requires a password, you will be promoted to enter it here. If it doesn't. you should be automatically connected.



7. Internet troubleshooting

I can't get a connection:

- Check that all cables are attached correctly and that your computer and router are switched on
- If you're using a wireless connection, try a wired connection instead to isolate where the problem lies
- Some laptops have a switch to turn the wireless connection off or on. Make sure this switch is set to 'on'
- Turn off both your computer and router. After a minute or so, turn them on and try again
- Make sure you've entered the web address in your browser correctly. For example: **http://www.seethelight.co.uk**

My connection is slow:

- Check your computer for viruses by running anti-virus software. You can get a free download of AVG anti-virus software at **www.seethelight.co.uk.**
- Empty your internet browser's cache. If you are unsure how to do this, consult your browser's help menu.

I get an error message when I connect my PC to the wireless network:

- Try disabling your computer's firewall and try again, remember to ensure that you have your firewall enabled before connecting to the internet
- If your connection works when the firewall is disabled, then contact your supplier for further advice

If you've checked the above:

- Check that the correct lights are illuminated on your router (for more on this see **4. About your router**)
- Check that the lights on your ONT are showing that your service is working properly (for more on this see **1. Your fibre equipment**)

Internet Service Test

If you're still having problems, it could be your internal wiring. You can connect your router directly to the ONT through data port 1 (see **2.2 A 'wired' connection**) to see if this is the case. Your internal wiring is the responsibility of the house owner/ landlord. To resolve an internal wiring problem, please contact a qualified electrician. If a seethelight technician visits your premises and the issue is caused by an internal wiring fault, you may be charged a call out fee.